

Item: Stainless steel strap

INSTALLATION MANUAL

<p>1.</p>	<p>Prepare installation tools, stainless steel strap, buckles for stainless steel and hand gloves.</p>	
<p>2.</p>	<p>Pull out the stainless steel strap from the plastic box at necessary length for fixation.</p>	
<p>3.</p>	<p>Cut the stainless steel strap at appropriate length as per desire.</p>	
<p>4.</p>	<p>Prepare cutted stainless steel part to be placed through the buckle for stainless steel strap.</p>	








LEGAL NOTICE:

The product must be installed only by a competent trained person with installation practices and with sufficient knowledge of good safety and installation practices in respect of electrical equipment. PLAMEN accepts no liability concerning claims resulting from misuse, incorrect installation or ignored national safety regulations or other national provisions. Failure to follow the installation instructions may result in damage to the product and serious or fatal injury.

Item: Stainless steel strap

INSTALLATION MANUAL

5.	Pull stainless steel strap through the buckle and bend stainless steel strap at approximately 5cm length.	
6.	Press the stainless steel strap with crimping tool as shown on right picture..	
7.	Pull the other end of the stainless steel strap through the buckle as shown on right picture and tension the strap as much as can by hand.	
8.	Place stainless steel strap into the tensioning tool for stainless steel strap and fix the strap into the tool.	
9.	Use tensioning tool for stainless steel strap and tension the strap adequately to situation.	








LEGAL NOTICE:

The product must be installed only by a competent trained person with installation practices and with sufficient knowledge of good safety and installation practices in respect of electrical equipment. PLAMEN accepts no liability concerning claims resulting from misuse, incorrect installation or ignored national safety regulations or other national provisions. Failure to follow the installation instructions may result in damage to the product and serious or fatal injury.

Item: Stainless steel strap

INSTALLATION MANUAL

<p>10.</p>	<p>Bend stainless steel strap as on right picture together with tensile tool.</p>	
<p>11.</p>	<p>1. Unfix the stainless steel strap from the tensile tool. 2. Pull out the tensile tool of stainless steel strap.</p>	
<p>12.</p>	<p>Knock with hammer the pits (both) presented on the right picture of stainless steel strap to the strap.</p>	
<p>13.</p>	<p>After previous step is done, stainless steel strap with buckle is fixed to the pole.</p> <p style="text-align: center;"></p>	



LEGAL NOTICE:

The product must be installed only by a competent trained person with installation practices and with sufficient knowledge of good safety and installation practices in respect of electrical equipment. PLAMEN accepts no liability concerning claims resulting from misuse, incorrect installation or ignored national safety regulations or other national provisions. Failure to follow the installation instructions may result in damage to the product and serious or fatal injury.