

CODE: P412921, P412924

Item: PG Connectors UNIMAX AL 6-95/1, UNIMAX AL 16-50/1

INSTALLATION MANUAL

1.	Before connector installation, it is recommended to clean the conductors with steel brush of dirtiness and/or dust.	
2.	Unscrew bolt of PG connector to have enough space to place conductors into clamp.	
3.	Place the conductors (branch and main) in the parallel grooves of the connector as shown on the picture.	
4.	Screw the bolt of PG connector with adequate wrench till rated torque value which is designated on the PG connector.	13 mm
5.	PG connector is now ready for exploitation.	